



SAFETY CABINETS FOR PHYTOSANITARY PRODUCTS



▲ AL57



▲ AL117



▲ AL157



▲ AL307

Fume hoods, filtering cabinets - Ventilation

Lithium-ion cabinets

Flammable cabinets

Corrosive cabinets

Toxic cabinets and Multirisk

Containment and cans

File cabinets Anti-fire equipments

Showers and first-aid equipments

COMPLIANCE

- In accordance to the legislation :
 - Articles R.5132-66 and R.5132-68 of the Public Health Code.
 - Article 4 of decree n° 87-361 of 27 May 1987 concerning the protection of workers.
- Standardized labelling in accordance to ISO 3864 and NF X08.003 standards, and with European Directive 92/58/EEC.

ADVANTAGES

- Allows the storage of your phytosanitary products in complete safety and in compliance with the legislation.
- Recommended for the storage of herbicides, fungicides, insecticides and other plant protection products.
- Recommended for farmers, breeders, wine growers, landscapers, horticulturists, agricultural cooperatives, green spaces, communities...

PASSIVE SAFETY

- 8/10th steel construction.
- Grey RAL 7035 electrostatic powder coating.
- Steel retention shelf, 50mm high, adjustable in height on a rack in 25mm increments (admissible load per shelf evenly distributed: 30 or 60kg).
- Steel Containment sump, 50mm high at the bottom of the cabinet.
- Complete Standardized labelling : including «toxic products» symbol and personal protective equipment symbols.

ACTIVE SAFETY

- Top and bottom ventilation holes on the sides.
- Hinged door(s) with key lock.

OPTIONS

- Additional steel shelf/Containment sump.
- PVC over-shelf/Containment sump.
- Perforated cover plate for containment sump.
- Absorbent mat.

P/N	Description	External dim. H x W x D (mm)	Internal dim. H x W x D (mm)	Storage capacity (L)	Containment capacity (L)	Number of shelves	Load capacity per shelf (kg)	Weight (kg)
AL57	1 door counter cabinet	1000 x 500 x 420	930 x 480 x 390	70	20	2	30	26
AL117	2 door counter cabinet	1000 x 920 x 420	930 x 900 x 390	135	40	2	60	40
AL157	1 door tall cabinet	1800 x 500 x 420	1730 x 480 x 390	130	40	4	30	41
AL307	2 doors tall cabinet	1800 x 920 x 420	1730 x 900 x 390	240	80	4	60	60
ESAL155	Containment shelf/ sump for 1 door cabinet	65 x 480 x 375			10			3
ESAL305	Containment shelf/ sump for 2 doors cabinet	65 x 900 x 375	-	-	20	-	-	6
SEAL155	Containment shelf/ sump in PVC for 1 door cabinet	-	-	-	10	-	-	2
SEAL305	Containment shelf/ sump in PVC for 2 doors cabinet	-	-	-	20	-	-	3
JF10D	Absorbent mats, small and large widths (pack of 10 sheets)							1