



1 HOUR 30 FIRE RESISTANT SAFE FOR DOCUMENTS



shelf for suspension files (optional)



▲ 793+DE



▲ 795+DE

COMPLIANCE

- Tested and approved to NT Fire 017-90 Paper, 1.5 hours fire resistance.

ADVANTAGE

- Allows safe storage of your paper documents.
- Fire resistance of 1 hour 30 minutes according to the ISO 834 standard curve.
- Full-height handle for easy opening and better ergonomics.
- Legs for easy movement by pallet truck: avoids heavy handling and allows the cabinet to be moved easily in the event of a new layout.
- Aesthetic and easy to use skirting board cover without the need for fixing tools.

TECHNICAL CHARACTERISTICS

- Double wall construction:
- External walls in 12/10th thick steel with white epoxy paint RAL 9010.
- Internal walls in melamine, color white RAL 9010.
- 50 mm thick thermal insulation panels between the walls to limit

thermal bridges.

- Shelves with height-adjustable ledges in 64 mm increments.
- Hinged door(s) with key lock.

OPTIONS

- Additional shelf.
- Shelf for hanging files.
- Colored doors are available for 794+DE and 795+DE: white frame and shelf RAL 9010; yellow door(s) RAL 1023.
- Numeric code lock.

NUMBER OF FILES PER SHELF

Folder width (mm)	Shelf E48 / EDS48	ShelfE35 / EDS35
50	8	18
70	6	13

P/N	Description	External dim. H x W x D (mm)	Internal dim. H x W x D (mm)	Number of shelves	Maximum load by shelf (kg)	Weight (kg)
798+DE	1 door counter cabinet for documents	1100 x 635 x 620	820 x 490 x 410	2	30	191
793+DE	2 doors counter cabinet for documents	1100 x 1137 x 620	820 x 1000 x 410	2	50	332
794+DE	1 door tall cabinet for documents	1900 x 635 x 620	1620 x 490 x 410	3	30	319
795+DE	2 doors tall cabinet for documents	1900 x 1137 x 620	1620 x 1000 x 410	3	50	448
EDS48	Suspension file shelf for 798+DE and 764+DE				60	3
EDS35	Suspension file shelf for 793+DE and 765+DE				100	6
E48	Additional shelf for 798+DE and 764+DE				30	3
E35	Additional shelf for 793+DE and 765+DE				50	4
SERCODE	Code lock					1

© ECOSAFE reserves the right to discontinue or change specifications or designs at any time without notice and without incurring obligations. 09/2021

Fume hoods, filtering cabinets - Ventilation

Lithium-ion cabinets

Flammable cabinets

Corrosive cabinets

Toxic cabinets and Multirisk

Containment and cans

File cabinets Anti-fire equipments

Showers and first-aid equipments