



SAFETY CABINETS FOR DANGEROUS PRODUCTS



Cabinets available in 4 different colours and 4 different and in 4 sizes

Fume hoods, filtering cabinets - Ventilation

lithium-ion cabinets

Flammable cabinets

Corrosive cabinets

Toxic cabinets and Multirisk

Containment and cans

File cabinets Anti-fire equipments

Showers and first-aid equipments

COMPLIANCE

- In accordance to articles R.5132-66 and R.5132-68 of the Public Health Code.
- Complies with the recommendations of the I.N.R.S.
- Standardized warning labels in accordance to NF X08.003, ISO 3864 and ISO 7010 standards, and with European Directive 92/58/EEC.

ADVANTAGES

- Allows the storage of your hazardous products in complete safety and in compliance with legislation.
- Economical solution for storing your hazardous products.
- Supplied with 4 warning labels: «Corrosive» (x2), «Toxic» and «Flammable» (to be affixed according to your use).
- Work surface of the counter cabinets (ref. AZ50 and AZ110) covered by a rubber mat.

ACTIVE SAFETY

- Top and bottom ventilation holes in the doors.
- Hinged door(s) with 110° opening angle.
- 3 points key lock.

PASSIVE SAFETY

- One-piece steel construction.
- Epoxy paint:
- Body grey RAL 7035; Door(s) yellow RAL 1023.
- Body grey RAL 7035; Door(s) red RAL 3000.
- Body grey RAL 7035; Door(s) blue RAL 5010.
- Body grey RAL 7035; Door(s) green RAL 6011.
- Shelves / containment sumps 50 mm high, height-adjustable on racks in 15 mm increments.
- Load capacity per level, evenly distributed, max. 80 kg.
- maximum per level.
- Standardized warning labels for «Flammable», «Corrosive» and «Toxic» products.

OPTIONS

- Additional shelf (ref.: ESE150 and ESE300).
- Galvanised grating for shelves / containment sumps (ref.: CE150 and CE300).
- Drilling for connection to a forced ventilation system. (ref. AZVENT), supplied with a Ø 100 mm sleeve (to be ordered
- (must be ordered with the cabinet).

P/N pour porte				Description	External dim. H x W x D (mm)	Storage (L)	Retention(L)	Number of shelves	Weight (kg)
Yellow	Rouge	Bleue	Verte						
AZ50	AZ50R	AZ50B	AZ50V	Armoire comptoir 1 porte	Ext. : 1000 x 500 x 500 Int. : 890 x 498 x 453	80	20	2	26
AZ110	AZ110R	AZ110B	AZ110V	Armoire comptoir 2 portes	Ext. : 1000 x 930 x 500 Int. : 890 x 925 x 453	155	40	2	43
AZ150	AZ150R	AZ150B	AZ150V	Armoire haute 1 porte	Ext. : 1950 x 500 x 500 Int. : 1840 x 498 x 453	150	40	4	55
AZ300	AZ300R	AZ300B	AZ300V	Armoire haute 2 portes	Ext. : 1950 x 930 x 500 Int. : 1840 x 925 x 453	300	80	4	90
ESE150	Shelf/bin for type AZ50 and AZ150				50 x 488 x 443	-	10	-	3
CE150	Shelf/bin grating for type AZ50 and AZ150				50 x 483 x 438	-	-	-	5
ESE300	Shelf/bin for type AZ110 and AZ300				50 x 915 x 443	-	20	-	6
CE300	Shelf/bin grating for type AZ110 and AZ300				50 x 913 x 438	-	-	-	10
AZVENT	Hole for ventilation connection				-	-	-	-	-

Refer to the table of chemical incompatibilities and precautions for use, to validate the configuration of your cabinet according to your needs.