

**RANGE P****CNPP - TNO - IBBC - NVBB**

# SECURIFLAMM SAFETY WASTE BINS



▲ 50RN

30MN ▲

▲ 18GP

## CERTIFICATION

- In compliance with authorized TNO and IBBC n° B 89.623 ANPI and NVBB N° NT 108.

## ADVANTAGES

- In case of fire inside the bin, the funnel form of the cover banishes the hot gases evacuation. The gases are sent back on the fire which is self-extinguished due to the lack of oxygene.  
- Many models available (capacity and color).

## TECHNICAL SPECIFICATIONS

- Built in steel 8/10<sup>th</sup>.  
- High hemmed anti-cut edges and low anti-scratch edges.  
- Funnel shaped safety cover makes the bin self-extinguishing.  
- Epoxy paint: Cover and body of pearl grey color, Black cover and red body; Black cover and steel gery body.  
- Capacity : 15, 30, 50, 80 and 110 litres.

P/N	Colour	Dimensions H x Ø (mm)	Capacity (L)	Weight (kg)
18GP	Pearl grey body and cover	360 x 255	15	1,7
18RN	Red body - Black cover	360 x 255	15	1,7
18MN	Steel grey body - Black cover	360 x 255	15	1,7
30GP	Pearl grey body and cover	470 x 335	30	3,9
30RN	Red body - Black cover	470 x 335	30	3,9
30MN	Steel grey body - Black cover	470 x 335	30	3,9
50GP	Pearl grey body and cover	625 x 335	50	4,6
50RN	Red body - Black cover	625 x 335	50	4,6
50MN	Steel grey body - Black cover	625 x 335	50	4,6
80GP	Pearl grey body and cover	510 x 450	80	8
80RN	Red body - Black cover	510 x 450	80	8
80MN	Steel grey body - Black cover	510 x 450	80	8
110GP	Pearl grey body and cover	710 x 450	110	9,3
110RN	Red body - Black cover	710 x 450	110	9,3
110MN	Steel grey body - Black cover	710 x 450	110	9,3

The manufacturer reserves the right to discontinue or change specifications or designs at any time without notice and without incurring obligations. 11/2014

Flammable  
cabinetsCorrosive  
cabinetsToxic cabinets  
and multiriskPesticide  
rangeFume hoods, filtering  
cabinets - VentilationContainment  
and CansAnti-fire equipments  
and Files cabinetsShowers and first-  
aid equipments