

# RANGE J



Fume hoods, filtering cabinets - Ventilation

Lithium-ion cabinets

Flammable cabinets

Corrosive cabinets

Toxic cabinets and Multirisk

Containment and cans

File cabinets Anti-fire equipments

Showers and first-aid equipments

## FOOT OPERATED OILY WASTE BINS



▲ 09101



▲ 09100

### COMPLIANCE

- Complies to FM (Factory Mutual), UL (Under-writers Laboratories) and TÜV specifications.
- Standardized labelling in accordance to ISO 3864 and NF X08.003, and European Directive 92/58/EEC.

### ADVANTAGES

- Easy opening by foot pedal.
- Natural ventilation allowing the evacuation of vapors.

### TECHNICAL CHARACTERISTICS

- Steel construction.
- Yellow or red epoxy paint.
- Foot pedal opening with automatic closing.
- Natural ventilation at the base of the bin.

P/N		Dimensions H x Ø (mm)	Capacity (L)	Compliance	Weight (kg)
Yellow	Red (not in stock)				
09101	09100	403 x 302	20	FM - UL - TÜV	6
09301	09300	464 x 354	34	FM - UL - TÜV	7
09501	09500	514 x 408	52	FM - UL - TÜV	8
09701	09700	595 x 467	80	FM - UL - TÜV	12

## RANGE A



## FIRE BLANKETS



▲ 180120RRP



▲ 120120RRP

### OPERATING PRINCIPLE

- The fire blankets are mounted on the wall and are equipped with two instantaneous opening tapes. In the event of a fire, simply pull them to deploy the blanket. They can be used to smother fires as soon as they start by acting as a heat shield, depriving the fire of its oxygen supply. They can protect both people and property.

### COMPLIANCE

- Complies with the European standard EN 1869-1997.

### ADVANTAGES

- Wall-mounted thanks to the box, allowing immediate viewing and quick access.
- Extra-flat, very light and very resistant.
- Instant opening by means of two tapes.

### TECHNICAL CHARACTERISTICS

- Made of fibreglass (420gr/m<sup>2</sup>), extra flat texture.
- Non-combustible, resistant to over 900°C.
- Instructions for use on the boxes.

P/N	Model	Case dimensions H x W x D (mm)	Dimensions of the cover (mm)	Compliance	Weight (kg)
180120RRP	Flat rectangular red wall box	360 x 160 x 35	1800 x 1200	EN	1
120120RRP	Flat rectangular red wall box	285 x 160 x 35	1200 x 1200	EN	1