



Fume hoods, filtering cabinets - Ventilation  
Lithium-ion cabinets  
Flammable cabinets  
Corrosive cabinets  
Toxic cabinets and Multirisk  
Containment and cans  
File cabinets  
Anti-fire equipments  
Showers and first-aid equipments

## COMPLIANCE

- Non-flammable insulating panels, classified A1 according to NF EN ISO 1182, between the walls.
- Fireproof construction certified EI 15 min type A1, according to NF EN 13501-1.
- Standardized warning labels in accordance to ISO 3864, ISO 7010 and NF X08.003, and to European Directive 92/58/EEC.

## CONSTRUCTION

- Double wall 12/10 steel construction.
- Mineral fibre insulation 20 mm thick in accordance to NF EN ISO 1182.
- White epoxy paint RAL 9010.
- Adjustable retention shelves on racks.

## EQUIPMENTS

- Ventilation by means of a lateral inner duct with opening at the top and bottom (Ø 100 mm).
- Roof ventilation outlet with connection sleeve (Ø 100 mm).
- Hinged doors with reinforced hinges with manual closing.
- Two-point locking.
- Key lock.

## OPTIONS

- Perforated shelves with 50 KG load capacity (Ref. E04LI or E06LI)
- Removable Containment sump at the bottom (Ref. GL04 or GL06)
- Fire extinguisher automatically triggered at 79°C by special lithium thermal bulb (Ref. EX100LI, EX200LI or EX500LI) (by smoke detection if included in the VIG190 / VIG290 / VIG590).
- Rack of 9 electrical sockets for recharging batteries (Ref. PRISELI / see the chart by country)

- Drilling in the lower part for cable passage with fireproof cable (Ref. PEXTBALI50)

## VENTILATION

All cabinet models are equipped with ventilation holes, allowing them to be connected to a ventilation system. Forced ventilation is strongly recommended to avoid internal heat build-up or stagnation of vapors in case of electrolyte leakage. This can be connected either to an external outlet or to a ventilation or filter box.

## ALARMWI DESCRIPTION

This Wi-Fi smoke detector alerts you if there is smoke or excessive heat build-up. It alerts you with an audible alarm for people nearby and an alert sent to your phone wherever you are.

- Easy to connect to your Wi-Fi, for alerts on your phone.
- Audible alarm to warn as many people as possible.
- Threshold of detection: 37 °C.
- Powered by 2x AA/LR6 battery.

## VENTILATION

All cabinet models are equipped with ventilation holes, allowing them to be connected to a ventilation system. Forced ventilation is strongly recommended to avoid internal heat build-up or stagnation of vapours in case of electrolyte leakage. This can be connected either to an external outlet or to a ventilation or filter box.

## NON-EQUIPPED CABINETS


P/N	Description	External dimensions H x W x D (mm)	Interior dimensions H x W x D (mm)	Empty weight without options
S804LI	2 doors counter cabinet to be equipped (depth 450)	895 x 1000 x 450 <sup>(1)</sup>	745 x 950 x 400	75
S806LI	2 doors counter cabinet to be equipped (depth 600)	895 x 1000 x 600 <sup>(1)</sup>	745 x 950 x 550	90
S2004LI	2 doors tall cabinet to be equipped (depth 450)	2095 x 1000 x 450 <sup>(2)</sup>	1945 x 950 x 400	152
S2006LI	2 doors tall cabinet to be equipped (depth 600)	2095 x 1000 x 600 <sup>(2)</sup>	1945 x 950 x 550	174

## PRE-EQUIPPED CABINETS

P/N	Description	External dimensions H x W x D (mm)	Weight (kg)
S804+LIA1	2 doors counter-top fire resistant cabinet for lithium batteries pre-equipped with 1 x E04LI shelf + 1 x EX100LI (fire extinguisher)	895 x 1000 x 450 <sup>(1)</sup>	77
S806+LIA1	2 doors countertop fire resistant cabinet for lithium batteries pre-equipped with 1 x E06LI shelf + 1 x EX100LI (fire extinguisher)	895 x 1000 x 600 <sup>(1)</sup>	92
S2004+LIA5	2 doors high fire resistant cabinet for lithium batteries pre-equipped with 5 shelves E04LI + 1 x EX200LI (fire extinguisher)	2095 x 1000 x 450 <sup>(2)</sup>	154
S2006+LIA5	2 doors high fire resistant cabinet for lithium batteries pre-equipped with 5 shelves E06LI + 1 x EX200LI (fire extinguisher)	2095 x 1000 x 600 <sup>(2)</sup>	176

(1) Depth including connecting sleeve at the back. Depth without sleeve: 400mm (S804LI) 550mm (S806LI)

(2) Height including connecting sleeve at top. Height without sleeve: 2045 mm



**15 min**  
Fire-resistant construction  
(from inside to outside)  
certified EI 15 min type A1,  
in accordance with standard NF EN 13501-1.



▲ S806+LIA1 + PRISELI + GL06 + PEXTBALI50



▲ S2004+LIA5 + 5 PRISELI + GL04 + 2 PEXTBALI50

## ACCESSORIES

Ref.	Description	Weight (kg)	Corresponding Cabinet(s)
E04LI	Perforated shelf (depth 450)	3	S804LI et S2004LI
E06LI	Perforated shelf (depth 600)	3,5	S806LI et S2006LI
GL04	Containment sump (depth 450)	4	S804LI et S2004LI
GL06	Containment sump (depth 600)	5	S806LI et S2006LI
EX100LI	Self-activating fire extinguisher at 79°C with special lithium bulb	2	S804LI et S806LI
EX200LI	Self-activating fire extinguisher at 79°C with special lithium bulb	3	S2004LI I
EX500LI	Self-activating fire extinguisher at 79°C with special lithium bulb	3	S2006LI
PEXTBALI50	Hole for cable passage with fireproof cable passage at the bottom (max. 4 cables)	-	Any model
PRISELI	Rack of 9 electrical sockets E+F (220 volts - 4000 watts - 16 amps - 50hz)	2	Any model
PRISELIF	Rack of 9 electric sockets type F (Germany)	2	
PRISELICH	Rack of 8 electrical sockets type J (Switzerland)	2	
PRISELIUK	Rack of 7 electrical sockets type G (United Kingdom)	1,7	
PRISELICC	Rack of 6 sockets equipped with a thermal-magnetic circuit breaker (4000 watts)	-	Any model
ONDULI	4-socket safety inverter for VIG190 or VIG290 or VIG590 (H 90 x W 163 x D 245 mm - 230 volts - 300 watts - 500 volts)	3,5	Any model
ALARMWI	Connected smoke detector with alarm on mobile application in case of triggering with wifi connection	-	-

© ECOSAFE reserves the right to discontinue or change specifications or designs at any time without notice and without incurring obligations. 05/2023

Fume hoods, filtering cabinets - Ventilation  
Lithium-ion cabinets  
Flammable cabinets  
Corrosive cabinets  
Toxic cabinets and Multirisk  
Containment and cans  
File cabinets  
Anti-fire equipments  
Showers and first-aid equipments