

RANGE AD79

NT Fire 017-90 Paper

1 HOUR 30 FIRE RESISTANT SAFE FOR DOCUMENTS



Shelf for suspension files

794DE ▶



798DE ▲



793DE ▲

▲ 795DE



CONFORMITY

- Tested and approved according to NT FIRE 017-90 Paper norm (90 minutes Fire resistance).

ADVANTAGE

- Allow to store in safety your documents and protect them against fire and robbery.
- 90 minutes Fire resistance according to ISO 834 heating curve.

TECHNICAL SPECIFICATIONS

- Double wall construction :
• Outer housing made of sheet steel (12/10th) with high quality Epoxy coating RAL 9010.
• Inner body built in white high pressure laminated.
- Thermal insulation panel between the walls avoiding thermal bridges.
- Handling door(s) with key-locking system.
- Shelves adjustable in height 64 mm pitch.

OPTIONS

- Additional shelf, contact us.
- Shelf for suspension files.
- Doors with different color possibilities on 794DE and 795DE models
• frame and shelves in white (RAL 9010); doors in yellow (RAL1023)

NUMBER OF WORKBOOKS SHELF



Width workbook (mm)	Shelf E48 / EDS48	Shelf E35 / EDS35
50	8	18
70	6	13

P/N	Description	Outside Dim. H x W x D (mm)	Outside Dim. H x W x D (mm)	Number of shelves	Maximum load by shelf ⁽¹⁾ (kg)	Weight (kg)
798DE	Working cover cabinet for documents, 1 door	1050 x 635 x 615	820 x 490 x 410	2	30	191
793DE	Working cover cabinet for documents, 2 doors	1050 x 1135 x 615	820 x 1000 x 410	2	50	332
794DE	Tall cabinet for documents, 1 door	1850 x 635 x 615	1620 x 490 x 410	3	30	319
795DE	Tall cabinet for documents, 2 doors	1850 x 1135 x 615	1620 x 1000 x 410	3	50	448
EDS48	Shelf for suspension files for 798DE and 794DE (load capacity: 60 kg ⁽¹⁾)				-	3
EDS35	Shelf for suspension files for 793DE and 795DE (load capacity: 100 kg ⁽¹⁾)				-	6
E48	Additional shelf for 798DE et 794DE (load capacity : 30 kg ⁽¹⁾)				-	3
E35	Additional shelf for 793DE et 795DE (load capacity : 50 kg ⁽¹⁾)				-	6

⁽¹⁾ Evenly distributed.

Flammable cabinets

Corrosive cabinets

Toxic cabinets and multirisk

Pesticide range

Fume hoods, filtering cabinets - Ventilation

Containment and Cans

Anti-fire equipments and Files cabinets

Showers and first-aid equipments