

RANGE 4

FM - NFPA - OSHA



FM SAFETY CABINETS FOR CORROSIVES⁽¹⁾

B18M ▶

B30M ▶



◀ B22S

CONFORMITY

- In compliance with NFPA (National Fire Protection Association), OSHA (Occupational Safety and Health Administration), UL (Underwriters Laboratories) and FM (Factory Mutual international) specifications.

ADVANTAGES

- Sturdy construction for use in industry.
- Integrated self-latching handle.
- Continuous piano hinge provides smooth closure.
- Various models available.

PASSIVE SECURITY

- Built in double wall steel with 38 mm of insulating air space.
- Blue epoxy paint.
- Adjustable galvanized spillslope safety steel shelves with high density polyethylene (HDPE) shelves trays.

- Liquid tight containment sump holds leaks on the bottom (50mm height).
- Static ground connection.
- B24M and B24S models equipped with extra polywork tray.

ACTIVE SECURITY

- High and low vent (Ø 50mm) with grid.
- Continuous piano hinge.
- Self-closing⁽²⁾ or manual doors.
- 3 points stainless steel bullet latching system.
- Doors with key-locking system.

OPTIONS

- Additional shelves.
- Industrial absorbent mats for retention tank (10 pieces by pack P/NJF10D).
- Ventilation or filtration boxes.

P/N	Closing doors	Outside dim. H x W x D (mm)	Inside dim. H x W x D (mm)	Storage capacity (L)	Containment capacity (L)	Number of shelves	HDPE protections	Maximum load by shelf ⁽³⁾ (kg)	W. (kg)
B04M	Manual	559 x 432 x 432	465 x 345 x 360	15	6	1	2	75	26
B04S	Slef-closing								28
B18M	Manual	610 x 1092 x 457	515 x 1005 x 390	64	20	1	2	75	58
B18S	Slef-closing								60
ESP18	-	Additional shelf for 64 litres cabinet							4
B22M	Manual	1651 x 591 x 457	1560 x 500 x 390	86	10	3	4	75	86
B22S	Slef-closing								88
ESP22	-	Additional shelf for 86 litres cabinet							2
B24M	Manual	910 x 890 x 560	710 x 795 x 455	90	18	1	2	75	92
B24S	Slef-closing								95
ESP24	-	Additional shelf for 90 litres cabinet							4
B30M	Manual	1118 x 1092 x 457	1025 x 1005 x 390	113	20	1	2	75	88
B30S	Slef-closing								90
ESP30	-	Additional shelf for 113 litres cabinet							4
B45M	Manual	1651 x 1092 x 457	1560 x 1005 x 390	170	20	2	3	75	121
B45S	Slef-closing								123
ESP45	-	Additional shelf for 170 litres cabinet							4
B60M	Manual	1651 x 864 x 864	1560 x 770 x 780	228	30	2	3	75	149
B60S	Slef-closing								151
ESP60	-	Additional shelf for 228 litres cabinet							8

⁽¹⁾ These cabinets are not designed for high corrosive products (nitric acid, sulfuric acid, phenol, hydrochloric) and require an exhausting system to improve their life cycle. For the high corrosive products please refer to our Ranges 8.A and 10. For the exhausting system refer our V Range.

⁽²⁾ According to models ⁽³⁾ Evenly distributed

The manufacturer reserves the right to discontinue or change specifications or designs at any time without notice and without incurring obligations. 07/2019

Flammable cabinets

Corrosive cabinets

Toxic cabinets and multirisk

Pesticide range

Fume hoods, filtering cabinets - Ventilation

Containment and Cans

Anti-fire equipments and Files cabinets

Showers and first-aid equipments