

SECURIFLAMM SAFETY WASTE BINS



▲ 50RN

▲ 30MN

▲ 18GP

COMPLIANCE

- Compliant to CNPP FSE 8414-D, TNO and IBBC approved No. B 89.623 ANPI and NVBB No. NT 108.

BENEFITS

- In the event of a fire inside the bin, the funnel-shaped smothering lid prevents hot gases from escaping and sends them back to the fire, which, deprived of oxygen, extinguishes itself.
- Many models available (in capacity and in colors).

TECHNICAL CHARACTERISTICS

- 8/10th steel construction.
- Anti-cut edges on the upper part and anti-scratch on the lower part.
- Funnel-shaped safety lid making the whole unit self-extinguishing.
- Epoxy paint: pearl grey lid and body; black lid and red body; black lid and metal grey body.
- Capacity: 15, 30, 50, 80 and 110 litres.

| P/N | Color | Dimensions H x Ø (mm) | Capacity (L) | Weight (kg) |
|-------|-----------------------------|-----------------------|--------------|-------------|
| 18GP | Pearl grey body and lid | 360 x 255 | 15 | 1,7 |
| 18RN | Red body - Black cover | 360 x 255 | 15 | 1,7 |
| 18MN | Metal grey body - Black lid | 360 x 255 | 15 | 1,7 |
| 30GP | Pearl grey body and lid | 470 x 335 | 30 | 3,9 |
| 30RN | Red body - Black lid | 470 x 335 | 30 | 3,9 |
| 30MN | Metal grey body - Black lid | 470 x 335 | 30 | 3,9 |
| 50GP | Pearl grey body and lid | 625 x 335 | 50 | 4,6 |
| 50RN | Red body - Black lid | 625 x 335 | 50 | 4,6 |
| 50MN | Metal grey body - Black lid | 625 x 335 | 50 | 4,6 |
| 80GP | Pearl grey body and lid | 510 x 450 | 80 | 8 |
| 80RN | Red body - Black lid | 510 x 450 | 80 | 8 |
| 80MN | Metal grey body - Black lid | 510 x 450 | 80 | 8 |
| 110GP | Pearl grey body and lid | 710 x 450 | 110 | 9,3 |
| 110RN | Red body - Black lid | 710 x 450 | 110 | 9,3 |
| 110MN | Metal grey body - Black lid | 710 x 450 | 110 | 9,3 |

© ECOSAFE reserves the right to discontinue or change specifications or designs at any time without notice and without incurring obligations. 09/2021

Fume hoods, filtering cabinets - Ventilation

Lithium-ion cabinets

Flammable cabinets

Corrosive cabinets

Toxic cabinets and Multirisk

Containment and cans

File cabinets
Anti-fire equipments

Showers and first-aid equipments