The manufacturer reserves the right to discontinue or change specifications or designs at any time without notice and without incurring obligations.

# ◈

## **SECURIFLAMM SAFETY WASTE BINS**

**CNPP - TNO - IBBC - NVBB** 



#### ▲ 18GP

#### **CERTIFICATION**

RANGE P

- In compliance with authorized TNO and IBBC  $n^{\circ}\,B$  89.623 ANPI and NVBB  $N^{\circ}\,NT$  108.

### **ADVANTAGES**

- In case of fire inside the bin, the funnel form of the cover banishes the hot gases evacuation. The gases are sent back on the fire which is self-extinguished due to the lack of oxygene.
- Many models available (capacity and color).

#### **TECHNICAL SPECIFICATIONS**

- Built in steel 8/10th.
- High hemmed anti-cut edges and low anti-scratch edges.
- Funnel shaped safety cover makes the bin self-extinguishing.
- Epoxy paint: Cover and body of pearl grey color, Black cover and red body; Black cover and steel gery body.
- Capacity: 15, 30, 50, 80 and 110 litres.

| P/N   | Colour                        | Dimensions<br>H x Ø (mm) | Capacity<br>(L) | Weight (kg) |
|-------|-------------------------------|--------------------------|-----------------|-------------|
| 18GP  | Pearl grey body and cover     | 360 x 255                | 15              | 1,7         |
| 18RN  | Red body - Black cover        | 360 x 255                | 15              | 1,7         |
| 18MN  | Steel grey body - Black cover | 360 x 255                | 15              | 1,7         |
| 30GP  | Pearl grey body and cover     | 470 x 335                | 30              | 3,9         |
| 30RN  | Red body - Black cover        | 470 x 335                | 30              | 3,9         |
| 30MN  | Steel grey body - Black cover | 470 x 335                | 30              | 3,9         |
| 50GP  | Pearl grey body and cover     | 625 x 335                | 50              | 4,6         |
| 50RN  | Red body - Black cover        | 625 x 335                | 50              | 4,6         |
| 50MN  | Steel grey body - Black cover | 625 x 335                | 50              | 4,6         |
| 80GP  | Pearl grey body and cover     | 510 x 450                | 80              | 8           |
| 80RN  | Red body - Black cover        | 510 x 450                | 80              | 8           |
| 80MN  | Steel grey body - Black cover | 510 x 450                | 80              | 8           |
| 110GP | Pearl grey body and cover     | 710 x 450                | 110             | 9,3         |
| 110RN | Red body - Black cover        | 710 x 450                | 110             | 9,3         |
| 110MN | Steel grey body - Black cover | 710 x 450                | 110             | 9,3         |